


PX FXP + PIV



PX FXP + PIV		
TYPE	Y1	Y2
700	653-700	-
800	753-800	777-816
900	853-900	877-916
1000	953-1000	977-1016
1100	-	1077-1116